



**GH-1860 ZX DRO RFS  
GH-1880 ZX DRO RFS**

**METAL LATHE**

**50000751T-50000765T  
400/50/3**

## **PARTS LIST**



**JPW Tool Group Hong Kong Limited**  
98 Granville Road, Tsimshatsui East, Kowloon, Hong Kong, PRC  
[www.jettools.com](http://www.jettools.com)

**Импортёр в РФ: ООО «ИТА Технолоджи»**  
105082, Москва, Переведеновский пер., д. 17  
[www.jettools.ru](http://www.jettools.ru)

Made in PRC / Сделано в КНР

## Table of Contents

Table of Contents .....	1
Stand Assembly .....	2-4
Brake Assembly .....	5-6
Bed Assembly .....	7-9
Headstock Assembly I .....	10-13
Headstock Assembly II .....	14-16
Headstock Assembly III .....	17-18
Headstock Assembly IV .....	19-20
Change Gear Box Assembly I .....	21-22
Change Gear Box Assembly II .....	23-24
Quick Change Gear Box I .....	25-27
Quick Change Gear Box II .....	28-29
Quick Change Gear Box III .....	30-31
Apron Assembly I .....	32-34
Apron Assembly II .....	35-38
Apron Assembly III .....	39-40
Carriage Assembly .....	41-43
Carriage Stop Assembly .....	44-45
Four Way Tool Post .....	46-47
Tailstock Assembly I .....	48-49
Tailstock Assembly II .....	50-51
Steady Rest Assembly .....	52-53
Follow Rest Assembly .....	54-55
Coolant And Work Light Assembly .....	56-57
Micro Carriage Stop Assembly .....	58
Protecting Guards For Three Rods .....	59
Safety Guard Cover .....	60
Parts List For Toolpost Protection Device .....	61
Parts List For Lead Screw Protection Device .....	62
Carriage Lubrication .....	63
Other Parts .....	64
Electrical Components .....	65
Electric Cabinet .....	66
Wiring Diagram .....	67
Flexible Stainless Wire Woven Tube .....	68

## **Stand Assembly**

## Stand Assembly

<b>Index</b>	<b>Part</b>			
<b>No.</b>	<b>No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
1	ZX01101AE	Pulley .....		1
2	ZXS2	Cylindrical End Set Screw .....	M8x16.....	1
3	ZX01734-G	Cover .....		1
4	ZXS4	Cross Head Screw.....	M6x14.....	4
5	ZXS2	Cylindrical End Set Screw .....	M8x16.....	1
6	ZX01701	Pedal Rod Support .....		1
10	ZX01102BN-G	New Bed Stand (for 60" models) .....		1
	ZX01102CN-G	New Bed Stand (for 80" models) .....		1
11	ZX01703	Fixed Support .....		1
12	TS1514021	Socket Head Cap Screw .....	M6x14.....	4
13	ZXS13	Taper Pin.....	5x20.....	2
14	ZX01705	Water Leaking Chip Guard .....		1
15	ZXS15A	Cross Head Screw.....	M5x20.....	4
16	TS1540121	Hex Nut.....	M20 .....	9
17	ZX01702	Bolt.....		3
18	TS1550111	Flat Washer.....	A20 .....	6
19	ZX01122B	Motor Mounting Plate .....		1
20	ZX01726-G	Cover .....		1
21	ZXS4	Cross Head Screw.....	M6x14.....	4
22	ZXS22	Key .....	10x8x70.....	1
23	ZXS23B	Main Motor .....	7.5HP, 6P, 3Ph .....	1
23a	GH16/GH18ZXK991	Main Motor Label (not shown) .....		1
24	ZX017609B	Wire Conduit (for 1860ZX).....		1
	ZX017609C	Wire Conduit (for 1880ZX).....		1
26	ZX01706	Locking Plate .....		1
28	ZXS15	Cross Head Screw.....	M4x6.....	1
29	ZX01711-G	Water Reception Plate.....		1
30	ZXS4	Cross Head Screw.....	M6x14.....	2
31	ZX01510	Coolant Tank.....		1
32	ZX01714-G	Cover .....		1
33	ZXS4	Cross Head Screw.....	M6x14.....	6
34	ZXS34	Nut .....	M3 .....	4
35	ZXS35	Coolant Indicator.....		1
36	ZXS36	Cross Head Screw.....	M3x20.....	4
37	TS1540072	Hex Nut.....	M10 .....	4
38	TS1550071	Flat Washer.....	M10 .....	4
39	TS1491041	Hex Cap Bolt.....	M10x30.....	4
80	ZX01716B-G	Stand Front Cover (for 1860ZX) .....		1
	ZX01716C-G	Stand Front Cover (for 1880ZX) .....		1
81	ZX01501	Gasket .....		1
82	ZXS82	Hex Nut.....	M5 .....	2
83	ZX01740	Left Tray .....		1
84	ZX01741	Right Tray .....		1

## Stand Assembly

<b>Index</b>	<b>Part</b>			
<b>No.</b>	<b>No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
85 .....	ZX01511.....	Gasket .....		2
86 .....	ZXS86 .....	Cross Head Screw.....	M5x16.....	6
87 .....	ZX01512 .....	Gasket .....		1
	JX21004.....	Terminal Board (not shown).....		1
	18301 .....	Junction Box (not shown) .....		1
	D974 .....	Plastic Fitting (not shown) .....		1
88 .....	ZX05753-G .....	Extending Plate.....		1
89 .....	ZX01703A.....	Fixed Support (serial # 7090341 and higher) .....		1
90 .....	ZXS91 .....	Flat Washer.....	.6.....	2
92 .....	JET-165.....	JET LOGO (serial #16081085 and higher).....		1
93 .....	GB2672-M6x20.....	Screw .....	M6x20.....	2
94 .....	C613618302 .....	Warning Label.....		1
95 .....	GH1440A18304-G .....	Wiring Box Cover.....		1
96 .....	GB818-M6x8.....	Cross Head Screw.....	M6x8.....	2
97 .....	GH1640ZX18303A-G ...	Wiring Box Cover.....		1

## **Brake Assembly**

## Brake Assembly

<b>Index</b>	<b>Part</b>				
<b>No.</b>	<b>No.</b>	<b>Description</b>		<b>Size</b>	<b>Qty.</b>
40	ZX22101-G	Fork			1
41	ZXS41	Spring Pin	5x40		1
42	ZX22703	Butt Nail Support			1
43	TS1524021	Set Screw	M8x10		1
44	ZXS44	Cross Head Screw	M5x20		4
45	ZX22714	Positioning Plate			1
46	ZX22704A	Driving Shaft-Longer			1
48	ZXS48	Spring Pin	5x30		2
49	ZX22712B	Pedal (for 1860ZX, serial # 7080340 and lower)			1
	ZX22712BE-G	Pedal (for 1860ZX, serial # 7090341 and higher)			1
	ZX22712C	Pedal (for 1880ZX, serial # 7080340 and lower)			1
	ZX22712CE-G	Pedal (for 1880ZX, serial # 7090341 and higher)			1
50	ZX22710C-G	Draw Bar			1
51	ZX22706	Connecting Shaft			1
52	ZXS52	Split Pin	2x20		2
53	ZXS53	Tensile Spring	3.5x26x190		1
54	ZXS54	Eyebolt	M8		1
55	TS1490091	Hex Cap Bolt	M8x50		1
56	TS1540061	Hex Nut	M8		1
57	ZX22707A	Butt Rod Support			1
58	TS1540072	Hex Nut	M10		1
59	ZXS59	C-Clip	8		1
60	ZX22701	Positioning Shaft			1
61	ZXS61	Brake Shoe			1
62	ZX22702	Brake Shaft			1
63	ZX22708	Connecting Plate			1
64	ZXS64	Elastic Pin	5x25		1
65	ZX22709	Connecting Shaft			1
66	ZXS66	Stroke Switch			1
67	ZXS67	Screw	M4x25		2
68	ZXS68	Cylindrical End Set Screw	M5x10		1
69	ZX22711	Butt Nail Support			1
70	ZXS70	Pin	5n6x20		1
71	ZX22715	Adjust Bolt			1
72	TS1540061	Hex Nut	M8		1
73	ZXS73	C-Clip	12		2
74	ZXS74	Hex Cap Bolt	M8x35		1

## **Bed Assembly**

## Bed Assembly

<b>Index</b>	<b>Part</b>			
<b>No.</b>	<b>No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
1	ZX01104B-G	Bed (for 1860ZX)		1
	ZX01104C-G	Bed (for 1880ZX)		1
2	TS1550101	Flat Washer	B16	8
3	ZXB3	Hex Cap Bolt	M16x50	8
4	<b>ZX01704A</b>	Rack		1
5	TS1516041	Hex Socket Cap Screw (for 1860ZX)	M10x35	14
		Hex Socket Cap Screw (for 1880ZX)	M10x35	18
6	ZXB6	Taper Pin (for 1860ZX)	8x50	14
		Taper Pin (for 1880ZX)	8x50	18
7	ZX01706A	Rack (for 1860ZX)		6
		Rack (for 1880ZX)		8
8	<b>ZX01112-G</b>	Saddle		1
9	TS1551081	Lock Washer	12	4
10	TS1517041	Hex Socket Cap Screw	M12x55	4
12	ZXB12	Thread Taper Pin	12x70	2
13	TS1491101	Hex Cap Bolt	M10x55	2
14	TS1550071	<b>Flat Washer</b>	M10	2
15	TS1503021	Hex Socket Cap Screw	M8x12	5
16	TS1550041	<b>Flat Washer</b>	Φ8	5
17	<b>ZX01741F-G</b>	Splash Guard (for 1860ZX)		1
	<b>ZX01741G-G</b>	Splash Guard (for 1880ZX)		1
18	ZXB18	Shear Pin	5x35	2
19	ZX01708BNE	New Lead Screw (for 60" models)		1
	ZX01708CNE	New Lead Screw (for 80" models)		1
20	ZXB20	Flat End Set Screw	M6x10	2
21	ZX01109N	New Sleeve		1
22	ZX1204	Double Row Spherical Ball Bearing	20x47x14	2
23	ZXB23	C-Clip	20	2
24	<b>ZX01110N-G</b>	New Bracket		1
25	<b>ZX01111-G</b>	Cover		1
26	TS1514021	Hex Socket Cap Screw	M6x14	4
27	ZXB27	Taper Pin	6x60	1
28	TS1516061	Hex Socket Cap Screw	M10x50	1
29	ZXB29	Oil Cup	10	2
30	TS223991	Hex Socket Cap Screw	M10x100	1
31	ZXB31	Taper Pin	6x100	1
32	ZX01108N	New Sleeve		1
33	ZX01709BN	New Feed Rod (for 60" models)		1
	ZX01709CN	New Feed Rod (for 80" models)		1
36	ZX01707B	Control Rod (for 1860ZX)		1
	ZX01707C	Control Rod (for 1880ZX)		1
38	<b>ZX06720</b>	Small Shaft		1
39	<b>ZX06001C-3</b>	Sleeve		1
40	ZX06001C-2	Spacer		1
41	ZXB41	Spring	1x75x25	3
42	<b>ZX06001C-1-G</b>	Bracket		1
43	TS1515011	Hex Socket Cap Screw	M8x16	2

## Bed Assembly

<b>Index</b>	<b>Part</b>		<b>Size</b>	<b>Qty.</b>
<b>No.</b>	<b>No.</b>	<b>Description</b>		
44	ZXB44	Lever		1
45	ZX06001C-4	Long Lever Sleeve		1
46	ZXB46	Hex Nut	M8	2
47	ZXB47	Set Screw	M8x28	2
48	ZX06001C-5	Direction Change Ring		1
49	ZXB49	Pin	8n6x20	1
50	ZXB50	Taper Pin	3x20	1
51	TS1516061	Hex Socket Cap Screw	M10x48	2
52	ZX05741	Threaded Tube		2
53	TS1540081	Hex Nut	M12	2
59	ZX01715C-G	Cover		1
60	ZXB60	Cross Recessed Pan Head Screw	M6x18	4
66	1440R01305	Plate (serial #16081100 and lower)		1
	GHB1340A01301-2	Plate (serial #16081101 and higher)		1
67	GB827-3x6	Rivet	3x6	4
90	C0632A01301E-G	Switch Box		1
91	ZXB91E	Hex Socket Cap Screw	M8x20	2
92	ZXB92E	Screw	M6x16	1
93	CO632A01705E	Bushing		1
94	ZXB94E	Steel Ball	6	1
95	ZXB95E	Spring		1
96	ZXB96E	Screw	M8x16	1
97	CO632A01504E-G	Switch Box Cover		1
98	ZXB98E	Hex Socket Cap Screw	M5x10	4
99	CO632A01503E	Plug		2
100	ZX01706E	Positioning Sleeve		1
101	ZXB101E	Screw	M5x8	1
102	ZLRLG18	Rubber Mat		1
103	ZXRRG	Rubber Mat		1
104	SQ2, SQ3	Stroke Switch	LXW5-11D1	2
105	GB97.2	Flat Washer	5	5
106	GB2672	Hex Socket Asterisk Pan Head Screw	M5x8	5
107	ZX-18717-G	Line Groove		1
108	C613618302	Warning Label		1

## **Headstock Assembly I**

## Headstock Assembly I

<b>Index</b>	<b>Part</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
<b>No.</b>	<b>No.</b>			
1	ZX02306	Round Sign Plate (serial #16081100 and lower)		1
	C6136ZK-02304-1	Round Sign Plate (serial #16081101 and higher)		1
1a	ZX02306	Round Sign Plate (serial #16081100 and lower)		2
	14~18R02303-2	Round Sign Plate (serial #16081101 and higher)		2
2	ZX02122-G	Positioning Handle		1
3	ZXH3	Flat End Set Screw	M10x12	1
4	ZXH4	Spring	YI-1x8x25	1
5	ZXH5	Steel Ball	8	1
6	ZXH6	Countersunk Head Screw	M5x12	2
7	ZX02743-G	Positioning Disc		1
8	ZX02738	Shaft		1
9	ZXH9	Taper Pin	5x55	1
10	ZXH10	Woodruff Key	4x16	1
11	ZXH11	Ring Seal	25x2.4	1
12	ZX02116	Crank		1
13	TS1523051	Set Screw	M6x16	1
14	ZXH14	Pin	5n6x28	1
15	ZX02302	Poking Block		1
16	ZX02738C	Pin Block		1
17	TS1523051	Set Screw	M6x16	1
18	ZX02114	Crank		1
19	ZXH11	Ring Seal	25x2.4	1
20	ZXH20	Pin	5x30	1
21	ZX02734	Shaft		1
22	ZXH10	Woodruff Key	4x16	1
23	ZXH5	Steel Ball	8	1
24	ZXH4	Spring	YI-1x8x25	1
25	ZXH3	Flat End Set Screw	M10x12	1
26	ZX02733-G	Left Positioning Disc		1
27	ZXH6	Countersunk Head Screw	M5x12	2
28	ZX02113-G	Left Lever Support		1
29	ZX02741-G	Handle		2
30	ZX02732	Cover		2
31	ZXH6	Countersunk Head Screw	M5x12	2
34	ZX02119-G	Right Lever Support		1
35	ZXH3	Flat End Set Screw	M10x12	1
36	ZXH4	Spring	YI-1x8x25	1
37	ZXH5	Steel Ball	8	1
38	ZX02728-G	Right Positioning Disc		1
40	ZXH6	Countersunk Head Screw	M5x12	2
41	ZXH10	Woodruff Key	4x16	1
42	ZX02727	Shaft		1
43	ZXH10	Woodruff Key	4x16	1
44	ZXH11	Ring Seal	25x2.4	1
45	ZX02730	Gear	1.5m36T	1
46	TS1523051	Set Screw	M6x16	1
47	ZX02738C	Pin Block		1

## Headstock Assembly I

<b>Index</b>	<b>Part</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
<b>No.</b>	<b>No.</b>			
48	TS1523051	Set Screw	M6x16	1
49	ZX02111	Crank		1
50	ZXH10	Woodruff Key	4x16	1
51	ZX02731/1	Control Shaft		1
52	ZXH10	Woodruff Key	4x16	1
53	ZXH11	Ring Seal	25x2.4	1
54	ZXH54	Taper End Set Screw	M6x16	1
55	ZX02732/2	Gear	1.5m36T	1
56	ZXH56	Ring Seal	40x3.1	1
57	ZX02110	Bushing		1
58	ZX02729	Cover		1
59	ZXH59	Pin	3n6x10	1
60	ZXH6	Countersunk Head Screw	M5x12	1
61	ZXH61	Countersunk Head Screw	M8x12	1
62	ZXH62	Flat End Set Screw	M8x12	1
63	ZX02115C	Bearing Support		1
64	ZXH64	Ring Seal	40x3.1	1
65	ZX02115	Left Fork		1
66	ZXH66	Flat End Set Screw	M6x10	1
67	ZX02120A/2	Bushing		1
68	ZXH68	Taper Pin	6x35	1
69	ZX02736	Control Shaft		1
70	ZX02112	Right Fork		1
71	ZXH66	Flat End Set Screw	M6x10	1
72	ZX02120A/2	Bushing		1
73	ZXH73	Ring Seal	30x3.1	1
74	ZX02735	Blocking Piece		1
75	ZXH61	Countersunk Head Screw	M8x12	1
76	ZX02744	Adjusting Screw		1
77	ZXH77	Taper Pin	8x40	2
79	ZX92124	Adjusting Block		1
80	ZXH80	Hex Cap Bolt	M12x50	1
81	ZX02744	Adjusting Screw		1
82	ZX02736C	Positioning Pin		1
83	ZXH83	Oil Sight Glass		1
84	ZXH84	Flat Washer	A16	2
85	ZXH85	Hex Socket Cap Screw	M16x50	2
86	ZX02301F	Label (for 1860ZX) (serial #16081100 and lower)		1
	ZX02301G	Label (for 1880ZX) (serial #16081100 and lower)		1
	GH1860ZX02301-303	Label (for 1860/1880ZX) (serial #16081101 and higher)		1
87	TS1504071	Hex Socket Cap Screw	M8x35	4
88	ZXH88	Countersunk Head Screw	M16x25	1
89	ZX02117-G	Top Cover		1
90	ZXH90	Hex Cap Bolt		2
91	ZXH91	Flat Washer	A16	2
92	ZX02505	Paper Gasket		1

## Headstock Assembly I

Index	Part	Description	Size	Qty.
No.	No.			
93	ZXH93	Cross Recessed Pan Head Screw (serial #16081100 and lower)	M3x6	13
	.....	.....	.....	.....
	.....	.....	.....	.....
94	ZXH94N	Pin	.4n6x15	2
95	ZXH95	Rubber Mat		1
96	ZX02740-G	Front Cover		1
97	GB97.2-6	Flat Washer	.6	2
98	GB818-M6x8	Cross Head Screw	M6x8	2
99	GHB1340A11304-12	Warning Sign Label (serial #16081101 and higher)		1

## **Headstock Assembly II**

## Headstock Assembly II

<b>Index</b>	<b>Part</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
No.	No.			
95	ZX02107	Pulley		1
96	TS1514041	Hex Socket Cap Screw	M6x25	4
97	ZX02106	Bearing Cover		1
98	ZX02506	Gasket		1
99	ZXH99	Ring Seal	32x52	1
100	BB6207	Ball Bearing	35x72x17	1
101	ZXH102	Sleeve	30x10	1
102	BB6207	Ball Bearing	35x72x17	1
103	TS1515031	Hex Socket Cap Screw	M8x25	6
104	ZX02105	Bearing Support		1
105	ZX02502	Gasket		1
106	ZXH106	Flat Key	10x8x35	1
107	ZX02709	Shaft		1
108	ZX02754X/6P	Gear	2.5m61T	1
109	ZX02753X/6P	Gear	2.5m32T	1
110	ZX02752X	Gear	2.5m18T	1
111	ZX02751X/6P	Gear	2.5m47T	1
112	ZXH112	Sleeve		1
113	BB6305/P6	Ball Bearing	25x62x17	1
114	ZXH114	Shaft End Lock Ring	32	1
115	ZXH115	Countersunk Head Screw	M6x20	1
116	ZXH59	Pin	3n6x10	1
117	ZXH117	Ring Seal	60x3.1	1
118	ZX02104-G	Blocking Flange		1
119	TS1514021	Hex Socket Cap Screw	M6x15	3
120	TS1514021	Hex Socket Cap Screw	M6x15	3
121	ZX19101-G	Blocking Flange		1
122	ZXH117	Ring Seal	60x3.1	1
123	BB6305	Ball Bearing	25x62x17	1
124	ZXH124	Sleeve	62x6	1
125	BB6305	Ball Bearing	25x62x17	1
126	ZXH126	Circle Clip For Shaft	35	1
127	ZX02705	Gear	3m19T	1
128	ZXH128	Flat Key	8x7x50	2
129	ZX02706	Gear	3m67T	1
130	ZX02707	Gear	3m59T	1
131	ZXH62	Flat End Set Screw	M8x12	1
132	ZX02708	Shaft		1
133	ZXH133	C-Clip	35	1
134	ZXH134	Sleeve	35x8	1
135	BB6007	Ball Bearing	35x62x14	1
136	ZXH136	Sleeve	35x8	1
137	ZXH133	C-Clip	35	1
138	ZX02756/6P	Gear	2.5m36T	1
140	ZX02757/6P	Gear	2.5m65T	1
141	ZX02758/6P	Gear	2.5m51T	1
142	ZXH142	Flat Key	10x6x60	2

## Headstock Assembly II

<b>Index</b>	<b>Part</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
No.	No.			
143 .....	ZXH143.....	Flat Head Set Screw .....	M8x12 .....	2
144 .....	ZX02755X/6P .....	Gear .....	2.5m22T .....	1
145 .....	ZXH133.....	C-Clip .....	35 .....	1
146 .....	BB6305 .....	Ball Bearing .....	25x62x17 .....	1
147 .....	ZXH147.....	Pushing Disc .....	62 .....	1
148 .....	ZX02109C.....	Cover .....		1
149 .....	TS1514021 .....	Hex Socket Cap Screw .....	M6x15 .....	3
150 .....	ZXH150.....	Set Screw .....	M12x65 .....	1
151 .....	ZXH151.....	Hex Nut .....	M12 .....	1
187 .....	ZXH187.....	Ring Seal .....	35x3.1 .....	1
188 .....	ZX02714 .....	Shaft .....		1
189 .....	ZX02716 .....	Double Gear .....	2m48T .....	1
190 .....	ZX02303 .....	Copper Sleeve .....		1
191 .....	ZX02734C.....	Positioning Sleeve .....		1
193 .....	TS1524041 .....	Set Screw .....	M8x15 .....	1
194 .....	ZX02733C.....	Blocking Piece .....		1
195 .....	ZX02718 .....	Taper End Set Screw .....		1
196 .....	ZX02114C.....	Sleeve .....		1
197 .....	BB6203 .....	Ball Bearing .....	17x40x12 .....	1
198 .....	ZXH198.....	C-Clip .....	28 .....	1
199 .....	ZX02717 .....	Gear .....	2m65T .....	1
200 .....	ZX02715 .....	Shaft .....		1
201 .....	ZXH201.....	Flat Key .....	5x5x1 .....	1
202 .....	ZXH198.....	C-Clip .....	28 .....	1
203 .....	ZX02722C.....	Sleeve .....		1
204 .....	ZX02301 .....	Oil Bushing (serial # 10100726 and lower) .....		1
	..... CDL50002302.....	Oil Bushing (serial # 10120727 and higher) .....		1
205 .....	ZX08106B-G.....	Bracket (for Shaft V, Vb) .....		1
206 .....	ZXH77.....	Taper Pin .....	8x40 .....	1
207 .....	TS1516021 .....	Hex Socket Cap Screw .....	M10x25 .....	1
208 .....	TNMP08706B (T).....	Gear .....	4m15T .....	1
209 .....	ZX02724C.....	Flat Washer .....		1
210 .....	ZXH59.....	Pin .....	3n6x10 .....	1
211 .....	ZXH211.....	Countersunk Head Screw .....	M5x16 .....	1
221 .....	VBA1981.....	V-Belt .....	A-1981 .....	4
233 .....	ZX02506 .....	Paper Gasket .....		2
234 .....	ZXH234.....	Set Screw .....	M8x6 .....	2
235 .....	ZX02743N.....	Clamping Round Nut .....		1
236 .....	ZXH236.....	Pin .....	8x30 .....	2
237 .....	ZXH237.....	Seal Ring (serial # 10120727 and higher) .....	25x40x70 .....	1
238 .....	ZXH238.....	Steel C-clip (serial # 10120727 and higher) .....	32 .....	1

## **Headstock Assembly III**

### Headstock Assembly III


<b>Index</b>	<b>Part</b>			
<b>No.</b>	<b>No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
152	ZX02704	Spindle		1
153	ZXH153	Flat Key	10x8x40	1
154	ZXH154	Flat Key	10x8x50	1
155	ZXH155	Flat Key	12x8x50	1
156	ZXH156	Flat Key	14x9x50	1
157	ZX02701	Cam Lock		6
158	ZXH158	Spring	1x8x25	6
159	ZX02703	Cam Positioning Screw		6
160	TS1516031	Hex Socket Cap Screw	M10x28	6
161	ZX02102-G	Bearing Front Cover		1
162	ZX02501	Gasket		1
163	ZX02702	Oil Splashing Ring		1
164	NN3024/P5	Taper Roller Bearing	120x180x46	1
165	ZX02726	Lining		1
168	ZX02725A	Round Nut w/Screw		1
169	ZX02723	Gear	3m98T	1
170	ZX02722	Gear	3m50T	1
171	ZX02721	Gear	3m58T	1
172	ZX02720A	Round Nut w/Screw		1
175	ZX02710	Gear	2m65T	1
176	51120/P5	Thrust Bearing	100x135x25	1
179	BB7020AC/P5	Angular Bearing	100x150x24	1
184	ZX02713A	Round Nut w/Screw		1
212	ZXH212A	Drain plug		1
213	ZX02101CN-G	Headstock Casting		1
224	ZXG38-3A	Screw		1
226	ZXH226	Hex Socket Cap Screw	M8x28	9
227	ZX02502F	Gasket (The part is canceled from serial # 13060962)		1
228	ZX02108F	Bearing Support		1
229	ZX02711F	Sleeve		1
230	ZX02510F	Gasket		1
231	ZX02761F	Bearing Back Cover		1
232	ZXH232	Screw	M5x10	6

## **Headstock Assembly IV**

## Headstock Assembly IV

<b>Index</b>	<b>Part</b>		<b>Size</b>	<b>Qty.</b>
<b>No.</b>	<b>No.</b>	<b>Description</b>		
214 .....	ZX08302C-G .....	Back Cover (for 18" models) (serial #18101183 and lower) .....		1
.....	ZX08719C-G .....	Back Cover (for 18" models) (serial #20101280 and high) .....		1
215 .....	ZX08114C-G .....	Rear Side plate (for 18" models) .....		1
216 .....	ZX08113C-G .....	Front Side plate (for 18" models) .....		1
217 .....	TS1515031 .....	Hex Socket Cap Screw .....	M8x25 .....	4
218 .....	ZXH218 .....	Taper Pin .....	6x25 .....	2
219 .....	TS1514031 .....	Hex Socket Cap Screw .....	M6x20 .....	8
220 .....	TS1514021 .....	Hex Socket Cap Screw .....	M6x15 .....	3
222 .....	ZX08712 .....	Upper Hinge .....		2
223 .....	ZXH223 .....	Pin .....	6n6x40 .....	2
225 .....	ZX08711 .....	Lower Hinge .....		2
226 .....	ZXH226 .....	Flat Washer (serial # 10040691 and higher) .....	6 .....	3
227 .....	ZXH227 .....	Spring Washer (serial # 10040691 and higher) .....	6 .....	3
228 .....	GH1860ZKK985 .....	Gear Box Sign Label (For GH1860ZX only) .....		1
.....	GH1880ZKK986 .....	Gear Box Sign Label (For GH1880ZX only) .....		1
229 .....	ZXH93 .....	Cross Recessed Pan Head Screw (serial #16081102 and lower) .....		
.....	.....	.....	M3x6 .....	4
.....	GB2672-M3x6 .....	Screw (serial #17121161 and higher) .....	M3x6 .....	4
230 .....	GHB-1340A11304-12 .....	Label Screw (serial #18041171and higher) .....		1
231 .....	C6250A-08704 .....	Cover (serial #20101280 and high) .....		1
232 .....	GB818 .....	Screw (serial #20101280 and high) .....	M6x10 .....	4


## Change Gear Box Assembly I



## Change Gear Box Assembly I

<b>Index</b>	<b>Part</b>			
<b>No.</b>	<b>No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
1	ZX08101-G	Change Gear Box Casting.....		1
2	ZX08108-G	Front Cover.....		1
5	ZX05104C-G	Hand Wheel.....		1
6	ZX05301C	Sign Plate (serial #16081100 and lower).....		1
	C6136ZK02304-1	Sign Plate (serial #16081101 and higher) .....		1
6a	GB2672-M3x6	Screw (serial #16081101 and higher).....M3x6.....		2
7	ZX08708	Positioning Disc .....		1
9	ZX08111	Crank .....		1
10	ZX08705	Connecting Rod.....		1
11	ZX08304	Sliding Block .....		1
12	ZX05103C	Cam .....		1
13	ZX05702C	Roller .....		2
14	ZX08109	Crank .....		1
15	ZX08110	Bushing.....		1
16	ZX08704	Rotating Shaft.....		1
17	ZX08703	Connecting Rod.....		1
18	ZX08304	Sliding Block .....		1
26	ZXC26	Cross Head Screw.....M4x12.....		3
28	TS1515031	Hex Socket Cap Screw.....M8x25.....		4
29	TS1516051	Hex Socket Cap Screw.....M10x40.....		2
30	TS1525021	Set Screw .....	M10x12.....	1
31	ZXC31	Flat Head Set Screw.....	M6x8.....	1
33	ZXC33	Taper Pin.....	4x45.....	1
34	ZXC34	Taper Pin.....	6x30.....	2
35	ZXC35	Taper Pin.....	6x50.....	1
36	ZXC36	Pin.....	10m6x40.....	2
37	ZXC37	Pin.....	10m6x50.....	2
38	ZXH5	Steel Ball.....	8.....	1
42	ZXC42	Spring .....	1x8x30.....	1
43	ZX-08716-G	Splash Guard.....		1
44	GB818-M6x12	Cross Recessed Pen Head Screw .....	M6x12.....	2
44a	GB97.2-6	Flat Washer.....	6.....	2
45	GB818-M5x12	Cross Recessed Pen Head Screw .....	M5x12.....	3
45a	GB97.2-5	Flat Washer.....	5.....	3
46	ZX-08715-G	Splash Guard.....		1


## Change Gear Box Assembly II



## Change Gear Box Assembly II

<b>Index</b>	<b>Part</b>			
<b>No.</b>	<b>No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
3	ZX08104-G	End Cover		4
4	ZX08103-G	Bearing Support		1
19	ZX08107	Gear	3m36T	1
20	ZX08105	Double Gear	3.75m28T/3m30T	1
21	ZX08702	Shaft		1
22	ZX08701	Shaft		1
23	ZX08710	Gear	3.75m27T	1
24	ZX08709	Gear	3m41T	1
25	ZX08102	Double Gear	3.75m30T/3m29T	1
27	ZXC27	Slotted Cheese Head Screw	M5x12	15
32	ZXC32	Flat Head Set Screw	M10x12	1
39	BB6203	Ball Bearing	17x40x12	5
40	ZXC40	C-Clip	25	4
41	ZXC41	C-Clip	40	1
43	ZXC43	Oil Cup	8	1
44	TNMP08108	Washer		1
45	TNMP08102	Splinted Sleeve		1
46	TNMP08504	Gear	3m45T	1
47	TNMP08501B	Gear	4m35T	1
48	ZX05502C	Oil Bushing		1
49	ZX08707	Shaft Vb		1
50	ZXC50	Flat Head Set Screw	M8x10	1

# Quick Change Gear Box I




## Quick Change Gear Box I

<b>Index</b>	<b>Part</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
No.	No.			
1	KLS1740A05152-G	Upper Cover		1
2	TS1514051	Hex Socket Cap Screw	M6x22	2
6	TS1515011	Hex Socket Cap Screw	M8x16	10
7	ZX05109-G	Rear Cover		1
8	ZX05502	Gasket		1
9	ZXQ09	Countersunk Head Screw	M10x18	1
10	ZX05101-G	Feedbox Casting		1
11	ZX05501	Gasket		1
12	ZX05108-G	Flange		1
13	TS1515011	Hex Socket Cap Screw	M8x16	6
14	ZX05151-G	Extending Plate		1
15	TS1503131	Hex Socket Cap Screw	M6x60	4
19	ZXQ19	Pipe	M10x10	1
20	TS1491061	Hex Cap Bolt	M10x40	2
21	ZXH68	Taper Pin	6x35	2
22	ZX05738	Control Shaft		1
23	ZX05739	Sliding Key		3
24	ZX05128	Sliding Sleeve		3
25	ZXQ25	Flat Head Set Screw	M5x8	4
26	ZX05125	Right Fork		1
27	ZX05126	Middle Fork		1
28	ZX05127	Left Fork		1
29	ZXQ29	Ring Seal	32x3.1	1
30	ZXQ30	Taper Pin (serial #12090914 and lower)	4x25	2
	GB877-4x30	Taper Pin (serial #12090915 and higher)	4x30	2
31	ZX05129	Cover		1
32	ZXQ32	Pin	5n6x15	1
33	ZXQ33	Cheese Head Screw	M5x16	3
34	ZX05122	Cam		1
35	ZX05728	Rolling Sleeve		5
36	ZX05729	Poking Key		3
37	ZX05123	Crank		1
38	ZXQ38	Pin	8n6x32	5
39	ZXQ39	Pin	6n6x20	5
40	ZX05124	Crank		1
41	ZX05111	Sleeve		1
42	ZX05726	Lever Shaft		1
43	ZXQ43	Taper Pin (serial #12090914 and lower)	4x32	2
	GB877-4x35	Taper Pin (serial #12090915 and higher)	4x35	2
44	ZXQ44	Taper Pin	4x65	1
45	ZX05121	Crank		1
46	ZX05118	Cam		1
47	ZX05120	Crank		1
48	ZX05116	Fork		1
49	ZXQ49	Pin	8n6x18	2
50	ZX05117	Sleeve		1
51	ZX05737	Lever Shaft		1

## Quick Change Gear Box I

<b>Index</b>	<b>Part</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
No.	No.			
52	ZXC33	Taper Pin	.4x45	2
53	ZX05115	Fork		1
54	ZX05119	Crank		1
55	ZX05735	Pin		1
56	ZX05112	Fork		1
57	ZX05113	Crank		1
58	ZX05730	Small Shaft		1
59	ZX05731	Big Gear	1m44T	1
60	ZX05732	Small Gear	1m22T	1
61	ZX05114	Sleeve		1
62	ZX05734	Lever Shaft		1
63	ZX05503	Gasket		1
64	ZX05110-G	Front Cover		1
65	TS1516011	Hex Socket Cap Screw	M10x20	5
66	ZXQ66	Taper Pin	.5x35	6
67	ZX05303A	Sign Plate (serial #16081100 and lower)		1
	GH1640ZX-08301-32	Sign Plate (serial #16081101 and higher)		1
68	ZXQ68	Cross Head Screw (serial #16081100 and lower)	M3x6	14
	GB2672-M3x6	Screw (serial #16081101 and higher)	M3x6	14
69	ZXQ69	Oil Sight Glass	20	1
70	ZX05727	Positioning Disc		1
71	ZXQ71	Countersunk Head Screw	M4x12	9
72	ZX05740-G	Lever		1
73	ZX05130A-G	Lever Support		1
73a	1440R05303	Taper Label (not shown)		1
	GB827-2x3	Rivet (not shown)	2x3	6
74	ZX05301	Sign Disc (serial #16081100 and lower)		2
	C6136ZK-02304-1	Sign Disc (serial #16081101 and higher)		2
74a	C6136-02306	Sign Disc		1
75	ZXH5	Steel Ball	.8	3
76	ZXQ76	Compression Spring	YZ-1x8x25	3
77	ZXH3	Flat End Set Screw	M10x12	3
78	ZX05736	Positioning Disc		1
79	ZX05140-G	Hand Wheel		2
80	ZX05733	Positioning Disc		1
81	C6136ZK05551	Rubber Washer		1
82	GB70-M8×5	Hex Socket Cap Screw	M8×5	1
83	1440R05752-G	Board		1


## Quick Change Gear Box II



## Quick Change Gear Box II

<b>Index</b>	<b>Part</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
No.	No.			
81	ZX05104	Middle Bearing Support.....		2
82	ZXQ82	Taper End Set Screw.....	M10x16.....	2
83	ZXB23	C-Clip .....	20 .....	3
84	ZXQ84	C-Clip .....	42 .....	5
85	BB6004	Single Row Radial Ball Bearing.....	20x42x12 .....	5
86	ZX05721	Shaft .....		1
87	ZX05722	Double Gear .....	2m26T/2m52T .....	1
88	ZXQ88	Iron Wire .....	1x190 .....	2
89	TS1524051	Set Screw .....	M8x20 .....	2
90	ZX05720	Positioning Sleeve .....		1
91	ZX05719	Gear .....	2.25m28T .....	1
92	ZX05718	Double Gear .....	2m26T/2m28T .....	1
93	ZX05717	Gear .....	3.5m20T .....	1
94	ZX05716	Double Gear .....	3.5m18T/3.5m19T .....	1
95	ZX05715	Gear .....	3.25m22T .....	1
96	ZX05714	Double Gear .....	3.25m24T/3.25m23T .....	1
97	BB6205	Single Row Radial Ball Bearing.....	25x52x15 .....	2
98	ZXC40	C-Clip .....	25 .....	3
99	ZX05125-G	Shaft End Cover .....		1
100	TS1515011	Hex Socket Cap Screw.....	M8x18 .....	2
101	ZX05704	Spacer .....		1
102	ZX05705	Double Gear .....	2m52T/2m26T .....	1
103	ZX05502C	Oil Bushing .....		3
104	ZX05105	Sleeve .....		2
105	ZX05707	Double Gear .....	2m39T/2m26T .....	1
106	ZXQ106	Iron Wire .....	1x160 .....	3
107	TS1524031	Set Screw .....	M8x12 .....	3
108	ZX05714C	Fixed Bushing .....		1
109	ZX05710	Shaft .....		1
110	ZX05709	Double Gear .....	2m48T/2.25m42T .....	1
111	ZX05711	Sliding Gear .....	3.5m24T .....	1
112	ZX05712	Sliding Gear .....	3.25m24T .....	1
113	ZX05713	Sleeve .....		1
114	ZXG51-1	Spacer .....	32 .....	1
115	ZX05106-G	Bearing Support .....		1
116	TS1515031	Hex Socket Cap Screw.....	M8x25 .....	3
141	ZX05504	Gasket .....		1
142	ZX05505	Gasket .....		1


### Quick Change Gear Box III



### Quick Change Gear Box III

<b>Index</b>	<b>Part</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
<b>No.</b>	<b>No.</b>			
66	ZXQ66	Taper Pin	5x35	4
83	ZXQ83	C-Clip	20	3
84	ZXQ84	C-Clip	42	5
85	BB104	Single Row Radial Ball Bearing	20x42x12	5
98	ZXQ98	C-Clip	25	3
106	ZXQ106	Iron Wire	1x160	3
107	TS1524031	Set Screw	M8x12	3
117	ZX05113C	Shaft Coupling		2
118	ZXQ118	Round Nut	M24x1.5	2
119	TS1503021	Hex Socket Cap Screw	M6x10	2
120	ZX05114-G	Cover		1
121	BB51105	Thrust Bearing	25x42x11	2
122	ZXQ122	Spacer	25	2
123	BB6305	Ball Bearing	25x62x17	1
124	ZX05725	Shaft		1
125	ZXQ125	Key	8x7x50	1
126	ZX05724	Double Gear	2.25m35T/2.25m36T	1
127	ZX05723	Gear	2.5m36T	1
128	ZX05107	Sleeve		2
129	BB6005	Ball Bearing	25x47x12	1
130	TS1525021	Set Screw	M10x12	2
131	ZX05103	Bearing Support		1
132	ZX05701	Shaft		1
133	ZXQ133	Woodruff Key	6x22	1
134	ZX05703	Gear	2.5m36T	1
135	ZX05102	Bearing Support		1
136	ZX05702	Double Gear	2.5m24T/2.25m35T	1
137	ZX05708	Shaft		1
138	ZX05706	Triple Gear	2m39T/2m52T/2m26T	1
139	BB6203	Ball Bearing	17x40x12	1
140	ZXQ140	C-Clip	17	1

## **Apron Assembly I**




## Apron Assembly I

<b>Index</b>	<b>Part</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
<b>No.</b>	<b>No.</b>			
1	ZXK06101-G	Apron Casting		1
2	ZXK06112-G	Bottom Cover		1
3	TS1540072	Hex Nut	M10	1
4	GB71	Flat Head Set Screw	M10x45	1
5	TL06502	Cushion Cap		1
6	ZXA06	Pin	.6n6x16	2
7	ZXA07	Tensile Spring	YI-1.2x9x50	1
8	ZXK06719A	Lever		1
9	ZXA09	Pin	.8n6x30	1
10	ZXA10	Pin	.6n6x18	1
11	TL06701-A	Pushing Rod		1
12	ZXA12	Oil Seal	.15x2.4	1
13	BB60016	Ball Bearing	.6x17x6	1
14	ZXA06	Pin	.6n6x12	1
15	ZXA15	Drain Plug	Z 1/4"	1
16	ZXB34	Taper Pin	.5x30	2
17	GB70	Hex Socket Cap Screw	M8x45	8
18	ZXK06501	Gasket		1
19	TL06307	Sign Plate (serial #16081100 and lower)		1
	C0632B05302-2	Sign Plate (serial #16081101 and higher)		1
19a	GB2672-M3x6	Screw (serial #16081101 and higher)	M3x6	6
20	ZX02741-G	Lever		1
21	C613206122-G	Lever Support		1
22	ZXB27	Taper Pin	.6x60	1
23	ZXK06706	Half Nut Shaft		1
24	TL06111Ab	Positioning Block		1
25	ZXA25	Thread Tail Taper Pin	.6x25	1
26	TS1523031	Set Screw	M6x10	1
27	C613606733	Half Nut Control Plate		1
28	ZXA28	Taper Pin	.6x55	1
29	C613606732	Pin		2
30	ZX06302E	Half Nut		1
31	TS1540072	Hex Nut	M10	1
32	ZXA32	Cylindrical End Set Screw	M10x55	1
33	C613606121	Gib		1
34	ZX06A731	Cylindrical End Set Screw		3
35	TS1540061	Hex Nut	M8	3
36	ZXA36	Set Screw	M8x32	1X
37	ZXA37	Oil Sight Glass	.20	1
69	TL06727N	Gear	2m25T	1
70	TL06728	Sliding Key		2
71	ZX06121A	Spacer		2
72	TL06304N	Worm bracket		2
73	ZXA73	Ring Seal For Rotating	.3x55	2
74	ZBJ2202	"O" ring	M33-B26503270	1
75	TL06729A	Sleeve		1
122	ZXK06302C	Sign Plate (serial #16081100 and lower)		1

## Apron Assembly I

<b>Index</b>	<b>Part</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
No.	No.			
.....	14-18R K06302C-1.....	Sign Plate (serial #16081101 and higher) .....		1
123 .....	TL06730.....	Shaft .....		1
124 .....	BB-51104 .....	Thrust Bearing .....	.25 x 35 x 10.....	2
125 .....	TL06305.....	Sleeve.....		1
126 .....	ZX06726A.....	Worm .....		1
127 .....	ZX06122A.....	Worm Support.....		1
128 .....	TL06720.....	Control Plate .....		1
129 .....	TS1514031 .....	Hex Socket Cap Screw.....	M6x16.....	2
130 .....	ZXA130 .....	Taper Pin.....	.4x20.....	1
131 .....	TS1524031 .....	Set Screw .....	M8x12.....	2
132 .....	ZXA132 .....	Screw .....	M8x25.....	2
133 .....	ZXA133 .....	Cylindrical Tensile Spring.....	L1-1.6x10x58.....	1
134 .....	TL06503.....	Gasket .....		1
135 .....	TL06114-G .....	Back Cover .....		1
136 .....	TS1514011 .....	Hex Socket Cap Screw.....	M6x12.....	5
137 .....	ZXA137 .....	Set Screw .....	M8x30.....	2
138 .....	ZXA138 .....	Iron Wire .....	.1x50.....	2
139 .....	ZXA139 .....	Oil Conducting Cord .....	3x100.....	2
140 .....	ZXA140 .....	Screw .....	M10x40.....	1
158 .....	TS1540041 .....	Hex Nut .....	M6 .....	1
159 .....	ZX06124A .....	Bracket .....		1
160 .....	ZXA160 .....	Pin .....	.5x16.....	2
161 .....	TL06308-G .....	Bracket .....		1
162 .....	GB70-M6x16 .....	Hex Socket Cap Screw.....	M6x16.....	1
200 .....	ZXK06721 .....	Cover .....		1
201 .....	ZXA201E .....	Cross Head Screw .....	M3x8.....	6
202 .....	GB97.1 .....	Flat Washer .....	.3.....	6
203 .....	ZXK06720 .....	Bracket .....		1
204 .....	ZXA204E .....	Head screw .....	M3x22.....	4
205 .....	LXW511N1 .....	Limit Switch .....		1
206 .....	TL06120 .....	Sleeve .....		1
207 .....	LXW511Q1 .....	Limit Switch .....		1
208 .....	ZXK18710 .....	Cover .....		1
209 .....	GB818 .....	Cross Head Screw .....	M5x10.....	2
210 .....	ZXK06726 .....	Sleeve .....		1
211 .....	GB70 .....	Hex Socket Cap Screw .....	M5x10.....	2
212 .....	ZXA212 .....	Bracket .....		1

## Apron Assembly II



## Apron Assembly II

<b>Index</b>	<b>Part</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
No.	No.			
38	GB894.1	C-Clip	20	2
39	6104	Ball Bearing	20x42x12	2
40	TL06705 (m)	Gear	2m66T	1
41	ZXA41	Taper Pin (serial #12090914 and lower)	6x40	1
	GB877-6x45	Taper Pin (serial #12090915 and higher)	6x45	1
42	GB893.1	C-Clip	40	2
43	ZXK06106	Bearing Support		1
44	TS1504041	Hex Socket Cap Screw	M6x16	3
46	GB893.1	C-Clip	42	2
47	ZXK06712	Shaft		1
48	ZXK06716	Hand Wheel Shaft	2mx15T	1
49	ZXH10	Half Circle Key	4x16	1
51	ZXK06109	End Cover		1
52	TS1514031	Hex Socket Cap Screw	M6x18	3
53	TL06105E	Dial Support		1
54	GB819	Cross Head Screw	M5x14	3
55	TL06732E	Dial		1
56	ZXK06107-G	Hand Wheel		1
57	ZX06710-G	Shaft Driven Lever		1
58	ZXK06713	Shaft Cover		1
59	GB819	Cross Head Screw	M5x20	1
60	ZXK06714	Screw		1
62	TL06112	End Cover		1
63	TS1514011	Hex Socket Cap Screw	M6x12	6
64	TL06733	T Shaped Flat Key		1
65	TL06115	Flange Sleeve		1
66	TS1514011	Hex Socket Cap Screw	M6x12	3
67	ZXA67	Flat End Set Screw	M6x30	1
68	TS1540041	Hex Nut	M6	1
76	TL06109-G	Flange		1
78	TL06303	Sign Plate (serial #16081100 and lower)		1
	TL06303-1	Sign Plate (serial #16081101 and higher)		1
79	TL06714	Adjusting Screw		1
80	ZXA80	Oil Seal	8x1.9	1
81	BB7203	Ball Bearing	17x40x12	2
82	ZXK06708	Shaft		1
83	TL06715	Adjusting Rod		1
84	ZXH10	Woodruff Key	4x16	3
85	TL06712	Spring Cover		1
86	ZXA86	Spring	YI-4x32x40	1
87	TL06718	Gear	2m28T	1
88	TL06113	Helical Gear	2.5m40T	1
89	BB7006/P6	Ball Bearing	30x55x13	1
90	TS1523031	Set Screw	M6x10	1
91	ZXA25	Thread Tail Taper Pin	M6x25	1
92	TL06110	Fork		1
93	ZXK06707	Control Rod		1


## Apron Assembly II

<b>Index</b>	<b>Part</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
No.	No.			
94	ZX06116E-G	Lever Support		1
95	ZXA95E	Cross Head Screw	M6x30	1
96	ZXH5	Steel ball	.8	1
97	ZXA97	Spring	YI-1x7x25	1
98	ZXA98	Flat Head Set Screw	M10x16	1
99	ZX06737E	Bracket		1
100	ZX06741E	Plug		1
101	ZX06739E-G	Gear shaft		1
102	ZXA102E	Hex head screw	M4x8	1
103	ZXA103E	Pin	.4x8	1
105	ZXK06105	Dial Support		1
107	ZXA107	Pin	.6n6x8	1
108	ZXK06701	Gear		1
109	ZXK06103-G	Bearing Seat		1
110	GB70	Hex Socket Cap Screw	M6x20	12
111	ZXK06718	Control Shaft		1
112	TL06725	Pin		1
113	ZXK06717	Control Block		1
114	ZXA114	Oil Seal	.20x2.4	1
115	ZXA115	Oil Seal	.60x3.1	1
116	ZXK06111	Lever Flange		1
117	TS1514011	Hex Socket Cap Screw	M6x16	3
118	ZXK06110-G	Lever Support		1
119	TL06307	Sign Plate (serial #16081100 and lower)		1
	C0632B05302-2	Sign Plate (serial #16081101 and higher)		1
120	ZXK06722-G	Lever		1
121	ZXB27	Taper Pin	.6x60	1
164	ZXA164E	Hex head screw	M6x35	3
165	ZX06738E	Rack		1
167	ZX06740E-G	Handle		1
168	ZX06736E	Washer		1
169	ZXA169E	Hex head screw	M5x10	1
170	ZX06303E	Label (serial #16081100 and lower)		1
	GH1640ZX06303-3	Label (serial #16081101 and higher)		1
171	ZXA171E	Screw (serial #16081100 and lower)	M3x5	8
	GB2672-M3x6	Screw (serial #16081101 and higher)	M3x6	8
172	YSS5634-G	Motor	370W, 1400r/min	1
173	GB1096	Key	B4x8	1
174	ZXK06701	Gear		1
175	ZXK06102-G	Bearing Seat		1
176	GB894.1	C-Clip	.17	1
177	GB308	Steel ball	.8	1
178	ZXK06108	Dial Support		1
179	GB819	Cross head screw	M6x14	3
180	GB73	Flat end set screw	M4x6	3
181	ZXK06301	Sleeve		1
182	ZXK06702	Gear		1

## Apron Assembly II

<b>Index</b>	<b>Part</b>			
<b>No.</b>	<b>No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
183 .....	ZXK06703 .....	Gear .....		1
187 .....	G51-2A.....	Oil Seal .....	25x2.4.....	1
188 .....	ZXK06104-G .....	Bearing Seat .....		1
189 .....	ZXK06704 .....	Gear .....		1
190 .....	ZXK06705 .....	Gear .....		1
191 .....	TL06301 .....	Sleeve .....		1
192 .....	GB73 .....	Flat End Set Screw .....		1
193 .....	ZXK06711 .....	Gear .....		1
194 .....	GB72 .....	Set screw .....	M8x10.....	1
196 .....	ZXA196E.....	Pin .....	4x16.....	1
197 .....	ZX197E .....	Head screw .....	M4x5.....	1
198 .....	ZXK18711 .....	Bracket .....		1
199 .....	ZX199E .....	Cross head screw .....	M4x8.....	2
200 .....	GB70 .....	Hex Socket Cap Screw .....	M8x25.....	3


### Apron Assembly III



### Apron Assembly III

<b>Index</b>	<b>Part</b>			
<b>No.</b>	<b>No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
141 .....	ZXA141 .....	Half Round Head Screw .....	M6x18.....	1
142 .....	ZX11704.....	Washer.....		1
143 .....	ZX11301.....	Dial (serial #16081100 and lower)		1
	ZX11302-3 .....	Dial (serial #16081101 and higher).....		1
144 .....	ZX11105 .....	Adjusting Washer.....		1
145 .....	ZX11701.....	Shaft .....		1
146 .....	ZXH10 .....	Half Circle Key .....	4x16.....	1
147 .....	ZXA147 .....	Half Round Head Screw (serial #16081100 and lower) .....	M3x6.....	6
	..... GB2672-M3x6.....	Screw (serial #16081101 and higher).....	M3x6.....	6
148 .....	ZX11303.....	Positioning Sign Plate.....		1
149 .....	ZX11703.....	Adjusting Washer.....		1
150 .....	ZX11101-G .....	Casting.....		1
151 .....	ZXA151 .....	Acorn Nut.....	M12 .....	1
152 .....	ZX11304.....	Thread Chasing Label (serial #16081100 and lower).....		1
	..... ZX11304-2 .....	Thread Chasing Label (serial #16081101 and higher).....		1
153 .....	ZX11102E .....	Helical Gear .....	2m15T .....	1
154 .....	TS1550071 .....	Flat Washer.....	M10 .....	1
155 .....	TS1540072 .....	Hex Nut.....	M10 .....	1
156 .....	ZX11702.....	Bolt.....		1
157 .....	ZXA157 .....	Oil Cup .....	8.....	2

## Carriage Assembly




## Carriage Assembly

<b>Index</b>	<b>Part</b>		<b>Size</b>	<b>Qty.</b>
<b>No.</b>	<b>No.</b>	<b>Description</b>		
1	ZXK04101A-G	Saddle Casting		1
2	ZX04505	Wipe Plate (serial # 9100690 and lower)		1
	ZX04505J	Wipe Plate (serial # 10040691 and higher)		1
3	ZX04504	Wipe Plate (serial # 9100690 and lower)		1
	ZX04504J	Wipe Plate (serial # 10040691 and higher)		1
4	ZXH211	Countersunk Head Screw (serial # 10040690 and lower) M5x16		11
	ZXC04	Half Round Head Screw (serial # 10040691 and higher) M5x16		11
5	ZX04724	Clamping Block		2
6	ZX04113	Lining Plate		2
7	TS1516031	Hex Socket Cap Screw	M10x30	4
8	TS1540061	Hex Nut	M8	4
9	ZXCA09	Square Set Screw	M8x20	4
10	ZX04506	Wipe Plate (serial # 9100690 and lower)		1
	ZX04506J	Wipe Plate (serial # 10040691 and higher)		1
11	TS1505071	Hex Socket Cap Screw	M10x45	8
12	ZXCA12	Square Cap Bolt	M12x60	1
13	ZXCA13	Taper Pin	8x60	2
14	ZX04729	Clamping Block		1
15	ZX04730	Locking Plate		1
16	ZXCA16	Pin	4n6x12	1
17	ZXK04772	Blocking Piece		1
21	ZX04782	Manual Oil Pump Casting		1
22	ZX04781A	In Valve		1
23	ZXCA23	Oil Ring	15x2.4	1
24	ZX04784	Piston		1
25	ZXCA25	Spring	1.2x14x65	1
26	ZX04785-G	Oil Pump Cover		1
27	TS1513031	Hex Socket Cap Screw	M5x16	2
28	ZX04783-G	Lever		1
29	ZXCA29	Countersunk Head Screw	M4x16	3
30	ZXA130	Taper Pin	4x20	1
32	ZX04716	Chip Guard		1
35	ZXK04740	Clamping Block		1
36	ZX04750	Oil Cap		1
37	ZX04301	Oil Indicator Cap		1
38	ZX04721-G	Lever		1
39	ZXCA39	Cross Head Screw	M5x16	1
40	ZX04720-G	Handle		1
41	ZX04769-G	Sleeve		1
42	ZXCA42	Round Nut	M12x1.25	4
43	ZX04719	Lining		1
44	ZX04770	Disc Spring		1
45	ZX04108-G	Flat Pan		1
46	ZX04790	Pushing Rod		1
47	ZX04789	Screw		1
48	ZX04717E	Dial		1
49	BB51102	Thrust Bearing	15x28x9	2

## Carriage Assembly

<b>Index</b>	<b>Part</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
No.	No.			
50	ZX04111	Sleeve		2
51	TS1490041	Hex Cap Bolt	M8x25	2
52	ZX04109E	Screw Support		1
53	ZXCA53	Oil Cup	8	2
54	ZXK04707-1	Gear Sliding Sleeve	2m, 16T	1
55	ZXH10	Woodruff Key	4x16	1
56	ZX04751	Flat Key		1
57	ZX04302	Nut Assembly		1
58	ZX04748	Wedge		1
59	ZXK04707-2(m)	Lead Screw		1
60	BB51101/P6	Thrust Bearing	12x26x9	2
61	ZX04116-G	Bracket		1
62	ZXCA62	Oil Cup	6	1
63	TS1491041	Cap Screw	M10x30	2
64	ZXCA64	Taper Pin	8x30	2
65	ZX04731	Cross Slide Gib		1
66	ZX04725C	Screw		2
67	ZXK04102	Cross Slide		1
68	ZX04714	Screw (T-Slot)		2
69	ZX04732	Pin		1
70	TS1540081	Hex Nut	M12	2
71	ZX04709	Sleeve		1
76	TS1504051	Socket Head Cap Screw	M8x22	3
77	ZX04502	Wipe Plate (serial # 9100690 and lower)		1
	ZX04502J	Wipe Plate (serial # 9100691 and higher)		1
78	ZXCA78	Copper Tube		6
79	ZX04503	Wipe Plate (serial # 9100690 and lower)		1
	ZX04503J	Wipe Plate (serial # 9100691 and higher)		1
80	ZX04771-G	Lining		1
81	ZX04788	Stop Pin		1
82	ZX04507	Stop Pin Cap		1
83	ZXK04803	Flange		2
84	GB70-M5x14	Hex Socket Cap Screw	M5x14	4
85	D96-5	Adaptor	M20x1.5	2
86	GB818-M4x6	Cross head screw (serial #16081100 and lower)	M4x6	2
	GB2672-M4x6	Screw (serial #16081101 and higher)	M4x6	2
87	ZXK04301	Plate		1
88	ZXK04802	Blocking Piece		2
89	ZXCA84	Oil Cup	10	3
90	ZXCA85	Turcite-B (not shown)	550x50x0.8	1
91	ZXCA86	Turcite-B (not shown)	550x25x0.8	2


## Carriage Stop Assembly



## Carriage Stop Assembly

<b>Index</b>	<b>Part</b>		<b>Size</b>	<b>Qty.</b>
<b>No.</b>	<b>No.</b>	<b>Description</b>		
1	ZX26101-G	Left Support		1
2	TS1504041	Hex Socket Cap Screw	M8x20	4
2a	GB5287-8	Thick Washer	.8	4
3	ZXC34	Taper Pin	.6x30	4
4	ZX26704-G	Control Ring		1
5	TS1523031	Set Screw	M6x10	2
6	ZX26702	Eccentric Travel Setting Ring		5
7	ZXH66	Flat End Set Screw	M6x10	10
8	ZXCS08	Pin	.4n6x10	5
9	ZX26703	Locking Key		5
10	ZX26701B	Travel Setting Rod (for 1860ZX)		1
	ZX26701C	Travel Setting Rod (for 1880ZX)		1
11	ZX26705-G	Control Ring		1
12	ZX26104-G	Right Support		1
13	ZXH5	Steel Ball	.8	1
14	ZXCS14	Compression Spring	2x8x25	1
15	ZXCS15	Flat Head Set Screw	M10x12	1
16	ZXCS16	Oil Cup	.8	2
17	ZX26301	Dial		1
17a	GB867-3x8	Dial	3x8	4
18	C6136ZK03303B	Plate		1


## Four Way Tool Post



## Four Way Tool Post

<b>Index</b>	<b>Part</b>		<b>Size</b>	<b>Qty.</b>
<b>No.</b>	<b>No.</b>	<b>Description</b>		
1	ZX04103C	Revolving Plate.....		1
2	ZX04725	Screw.....		1
3	ZX04710	Gib .....		1
4	ZX04786-G	Screw.....		1
5	ZX04303	Pressing Block.....		1
6	ZX04706E	Lead Screw .....		1
7	ZX04106AE	Nut .....		1
8	ZX04107B	Top Slide .....		1
9	ZX04501	Wipe Plate .....		1
10	ZXF10	Woodruff Key .....	3x13	1
11	BB51102	Thrust Bearing .....	15x28x9	2
12	ZX04115E	Sleeve.....		1
13	ZXF13	Slotted Cheese Head Screw .....	M5x12	3
14	ZXF14	Taper Pin.....	3x18	2
15	ZX04727E	Dial.....		1
16	ZX04114	Sleeve.....		1
17	ZX04768	Disc Spring .....		1
18	ZX04767-G	Sleeve.....		1
19	ZX04726-G	Handle .....		1
20	ZX04771-G	Lining .....		1
21	ZX04763	Spring .....	0.8x6x25	1
22	ZX04787	Positioning Block .....		1
23	ZX04752A	T-Slot Nut.....		1
24	ZX04754	Shaft .....		1
25	ZX04759-G	Adjusting Lining Sheet.....		1
26	ZX04110-G	Lever Support .....		1
27	ZX04753-G	Handle .....		1
28	ZXQ66	Taper Pin.....	5x35	1
29	ZX04713B	Tool post .....		1
30	ZXF30A	Clamping Screw.....	M12x45	8
31	ZXF31	Oil Cup .....	8	1
32	ZXH211	Countersunk Head Screw.....	M5x16	3
33	ZX04725C	Screw .....		1
34	ZXF34	Oil Cup .....	8	2
35	ZXF35	Spring .....	0.7x5x9	2
36	ZXF36	Steel Ball.....	6	2
37	ZXF37	Round Nut.....	M12x1.25	2
38	ZXCA39	Cross Head Screw.....	M5x16	1
39	ZX04746K-G	Screw Wrench .....		1
	ZXTA18-G	Toolholder Assy. (includes # 29 & 30)		
	ZXCPA18-G	Compound Assy. (includes # 1-20, 32-39)		



## Tailstock Assembly I



## Tailstock Assembly I

<b>Index</b>	<b>Part</b>			
<b>No.</b>	<b>No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
1	ZX03711-G	Handle		1
2	ZX03717-G	Lever Support		1
3	ZX03718	Washer		1
4	ZX03719	Clamping Block		1
5	ZX03720	Clamping Block		1
6	ZXT06	Cylindrical End Set Screw	.M8x14	2
7	ZX03712	Eccentric Shaft		1
10	ZX03701A	Center Sleeve		1
11	ZXT11	Ring Seal	75x2.65	1
12	ZX03703	Front Cover		1
13	ZXT13	Cross Recessed Countersunk Head Screw	.M5x10	4
14	ZXT14A	Center Morse	No.5	1
22	ZX03702	Positioning Block		1
35	ZX03714C	Eccentric Shaft		1
36	ZXT36	Taper Pin	.6x32	1
37	ZX03104-G	Lever Sleeve		1
38	ZX03709-G	Lock Handle		1
39	ZXA28	Taper Pin	.6x55	1
40	TS1504041	Hex Socket Cap Screw	.M8x20	4
41	TS1515031	Hex Socket Cap Screw	.M8x22	3
42	ZXT42	Pin	10n6x22	1
43	ZX03302	Sign Plate		1
45	ZXT45	Nail	.3x8	4
46	ZX03105E	Nut		1
47	BB51205	Thrust Ball Bearing	25x47x15	1
48	ZX03104E	Back Cover		1
49	ZX03103-G	Hand Wheel		1
50	ZX03707-G	Lever		1
51	ZXT51	Acorn Nut	.M16	1
52	TS2360161	Flat Washer	B16	1
53	ZXT53	Key	.6x40	1
54	ZX03710AE	Lead Screw		1
55	ZX03101A-G	Tailstock Casting		1
56	ZXT56	Oil Cup	.8	1
57	ZX03708E	Dial		1
58	ZX03706	Sleeve		1
59	ZX03711C	Spring Leaf		1
65	TS2310162	Nut	.M16	1


## Tailstock Assembly II



## Tailstock Assembly II

<b>Index</b>	<b>Part</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
No.	No.			
8	ZXT08	Flat End Set Screw	M6x18	4
9	ZXT09E	Spring		1
18	ZX03714	Bearing Support		4
19	ZX03715	Small Axle		4
20	ZXT20	Ball Bearing	7x19x6	4
21	ZX03102A-G	Sliding Base		1
23	TS1550071	Flat Washer	10	2
24	TS1491151	Hex Cap Bolt	M10x90	2
25	ZX03704	Gib		1
27	ZX03718C	Adjusting Screw		2
28	ZXT28	Taper Washer	16	2
29	ZXT29	Spherical Washer	16	2
30	TS2310162	Hex Nut	M16	2
31	ZX03106-G	Clamping Bracket		1
32	ZX03105C	Nut		1
33	ZXT33	Hex Socket Cap Screw (full thread)	M8x90	2
34	ZX03705A	Pulling Rod		2
44	ZX03303	Sign Plate		1
45	ZXT45	Nail	3x8	4
60	ZXT60	Half Round Head Screw	M5 x12	10
61	ZX03721	Plate		1
62	ZX03502	Wipe Plate		2
63	ZX03503	Wipe Plate		2
64	ZX03716	Plate		1
	ZXTSA18-G	Tailstock Assy. 18" (includes # 1-13, 15-65)		


## Steady Rest Assembly



## Steady Rest Assembly

<b>Index</b>	<b>Part</b>		<b>Size</b>	<b>Qty.</b>
<b>No.</b>	<b>No.</b>	<b>Description</b>		
1	ZX-10701E	Screw (for 16" models)		3
	ZX-10701F	Screw (for 18" models)		3
2	ZX-10705E	Sliding Sleeve (for 16" models only) (serial #16081085 and higher)	20-180	3
	ZX-10705E	Sliding Sleeve (for 18" models) (serial #16081085 and higher)	20-200	3
2a	GB119-8n6x24	Pin (serial #16081085 and higher)	8n6x24	3
3	608-RS	Bearing (serial #16081085 and higher)	8x22x7	3
4	ZX-SR04	Slotted Set Screw	M6x20	3
5	ZX-10705	Lever		3
6	ZX-10703D	Locking Screw		3
7	GB119-10n6x55	Pin	10n6x55	1
8	ZX10701	Hinge Screw		1
9	GB119-8n6x55	Pin	8n6x55	1
10	ZX-SR10	Hex Nut	M20	1
11	ZX-SR11	Flat Washer	20	1
12	ZX-10708	Tightening Screw		1
13	ZX-10103D-G	Clamping Plate		1
14	ZX10101E-G	Lower Part of Steady Rest (for 16" models)		1
	ZX10101F-G	Lower Part of Steady Rest (for 18" models)		1
15	ZX10102E-G	Upper Part of Steady Rest (for 16" models)		1
	ZX10102F-G	Upper Part of Steady Rest (for 18" models)		1
16	ZX-10701D	Knurling Nut		1
17	GB97.2-10	Flat Washer	10	1
	ZX-SRA16-G	Steady Rest Assembly, 16" (includes # 1-17)		
	ZX-SRA18-G	Steady Rest Assembly, 18" (includes # 1-17)		


## Follow Rest Assembly



### Follow Rest Assembly

<b>Index</b>	<b>Part</b>		<b>Size</b>	<b>Qty.</b>
<b>No.</b>	<b>No.</b>	<b>Description</b>		
1	ZX10710	Screw		2
2	ZX10704	Nut		2
3	ZX10707	Sliding Sleeve		2
4	ZX10301	Supporting Piece		2
5	ZXFR05	Slotted Set Screw	M6x10	2
6	ZX10705	Locking Screw		2
7	ZX10706	Handle		2
8	ZXFR08	Hex Cap Bolt	M12x55	2
9	ZX10102C-G	Follow Rest Casting		1
	ZXFRA18-G	Follow Rest Assy. (includes # 1-7, 9)		
10	GB97.2-12	Flat Washer		12

## Coolant & Work Light Assembly




## Coolant & Work Light Assembly


<b>Index</b>	<b>Part</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
No.	No.			
1	RT001B	Rubber Tube (for 1860ZX)	ID 1/2"x1780mm	1
	RT001C	Rubber Tube (for 1880ZX)	ID 1/2"x2280mm	1
2	ZXCW02	Hex Cap Bolt	M5x25	4
3	ZXCW03	Hex Nut	5	4
4	ZXCW04E	Coolant Pump		1
5	ZXCW05	Hex Nut	M6	2
6	ZX01727	Clip For Rubber Tube		2
7	ZXCW07	Half Round Head Screw	M6x16	2
8	ZX01728	Fitting		1
9	ZX01729	Flow Pipe		1
10	ZXCW10	Coolant Device		1
	ZXCW10-1	Coolant Tap	G3/8"	1
11	TS1514021	Hex Socket Cap Screw	M6x16	2
12	TS1515051	Hex Socket Cap Screw	M8x40	2
13	ZXCW13	Lamp Support		1
14	ZXS04	Cross Head Screw	M6x14	4
15	ZXCW16	Bulb (serial #16051084 and lower)	50W, AC24V	1
	ZX-EL	Machine Lamp (serial #16081085 and higher)	JC52B	1
	ZX-ELB	Bulb for led work light JC52B	3W,24V	1
16	ZX-WLCP01	Tube (for 40" models)	1.7m	1
	ZX-WLCP02	Tube (for 60" models)	2.2m	1
	ZX-WLCP03	Tube (for 80" models)	2.7m	1
17	K989	Label		1

## Micro Carriage Stop Assembly

Index	Part	Description	Size	Qty.
No.	No.			
1	ZX09709E	Dial		1
2	ZXMS2	Pin	B4x8	1
3	ZX09708	Axle		1
4	ZX09105-G	Stop		1
5	ZX03302	Sign Plate		1
6	ZXMS6	Nail	3x8	2
7	ZXMS7	Hex Socket Set Screw	M6x12	1
8	ZX09106	Clamping Plate		1
9	ZXMS9	Hex Socket Cap Screw	M8x20	2




## Protecting Guards For Three Rods


**Index Part**

No.	No.	Description	Size	Qty.
1 .....	ZX20701E-G .....	Splash Guard.....		1
2 .....	ZX20702E-G .....	Splash Guard.....		1
3 .....	ZXP03E.....	Hex Socket Cap Screw.....	M6x8.....	4
4 .....	ZXP04E.....	Flat Washer.....	.6.....	4
5 .....	ZX11304.....	Thread Chasing Label (serial #16081100 and lower) .....		1
.....	ZX11304-2 .....	Thread Chasing Label (serial #16081101 and higher) .....		1
6 .....	ZXA147 .....	Half Round Head Screw (serial #16081100 and lower) ..M3x6.....		6
.....	GB2672-M3x6.....	Screw (serial #16081101 and higher) ..M3x6.....		6

(Note: This device is optional)


## Safety Guard Cover


**Index Part**

No.	No.	Description	Size	Qty.
1	ZX19701E-G	Protection Guard		1
2	ZX19501E	Protection Guard Visual Glass		1
3	ZX19704E	Fixing Rod		1
4	ZXS04E	Handle (serial #16051084 and lower)	Z96-6	1
	A=90 Black	Handle (serial #16081085 and higher)		1
6	GB70-M6x12	Hex Socket Cap Screw (serial #16081085 and higher)	M6x12	2
7	ZXS07E	Hexagon Thin Nut	M4	4
8	ZXS08E	Plain Washer	.4	4
8a	GB96-4	Large Plain Washer	.4	4
9	ZXS09E	Cross Recessed Pan Head Screw	M4x12	4
10	ZXS10E	Plain Washer	.5	4
11	ZXS11E	Hexagon Socket Cap Head Screw	M5x16	4
12	ZX19703E	Rest Bar		1
13	ZXS13E	Slotted Set Screw	M8x10	2
14	ZXS14E	Hexagon Socket Cap Head Screw	M6x30	4
15	ZXS15E	Hexagon Socket Set Screw	M8x16	1
16	GH1440A19101E	Switch Box	LXW5-11Q1	1
17	ZXS17E	Stroke Switch		1
18	ZXS18E	Slotted Pan Head Screw	M4x25	2
19	ZX19702E	Shaft		1
20	ZX19502E	Gasket		1
21	ZXS21E	Nut	M8	1
22	GH-1640ZX19706	Board (serial # 16051084 and lower)		1
	GH-1640ZX19706B	Board (serial # 16081085 and higher)		1
23	GB97.2-6	Plain Washer	.6	2
24	GB6172-M6	Hex Nut		2

(Note: This device is optional)


## Parts List For Toolpost Protection Device


**Index Part**

No.	No.	Description	Size	Qty.
1	GH1640ZX20501	Shield		1
2	GH1640ZX20701	Clamping Screw		1
3	GH1640ZX20703	Washer		1
4	GH1640ZX20704	Sleeve		1
5	ZXTD05	Nut	M6	2
6	GH1640ZX20705-1	Bracket		1
7	ZXTD07	Hex Socket Cap Screw	M8x16	2
8	GH1640ZX20705-2	Bracket		1
10	ZXTD10	Washer	6	4
11	ZXTD11	Cross Recessed Pan Head Screw	M6x20	2

(Note: This device is optional)

## Parts List For Lead Screw Protection Device




### Index Part

No.	No.	Description	Size	Qty.
1	1440R07101-G	Cover		1
2	ZXLD02	Cross Recessed Head Screw	M6x12	2
3	1440R07701A	Left Flange		1
4	LGB451000-75	Telescoping Sheet Cover (1000 Size)		2
	LGB451500-100	Telescoping Sheet Cover (1500 Size)		2
	LGB452000-120	Telescoping Sheet Cover (2000 Size)		2
5	1440R07702A	Flange		1
6	ZXLD06	Cross Recessed Head Screw	M5x12	10
7	1440R07703A	Left Bracket		1
8	ZXLD08	Hex Socket Cap Screw	M8x20	4
9	1440R07704A	Right Bracket		1
10	1440R07706A	Sleeve		1
11	1440R07705A	Right Flange		1

(Note: This device is optional)

## Carriage Lubrication


<b>Index</b>	<b>Part</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
No.	No.			
1	ARM	Valve Tie-in .....		1
2	206254	Clip Sleeve.....	CS-6 .....	2
3	206252	Vitta Tie-in .....	CB-6 .....	2
4	CL-04	Nylon Pipe .....	Φ6 .....	0.4m
5	CL-05	Spring Sleeve .....	Φ6 .....	0.2m
5a	PC-4-1	Nip .....	Φ4 .....	3
5b	GB70-M5×10	Hex Socket Cap Screw.....	M5×10 .....	3
6	106095	Tie-in .....	SA-4-6 .....	1
7	CL-07	Tie-in .....	KC-4 .....	4
8	CL-08	Nylon Pipe .....	Φ4 .....	0.7m
9	CL-09	Spring Sleeve .....	Φ4 .....	0.7m
10	106252	Vitta Tie-in .....	CB-4 .....	4
11	106254	Clip Sleeve.....	CS-4 .....	4
12	106255	Plug.....	CP-4 .....	1
13	106411	Connector .....	PJ-6D .....	1
14	GB70 M5×20	Hex Socket Cap Screw.....	M5×20 .....	2



(Note: This device is installed from serial #14041007)




## Other Parts

<b>Index</b>	<b>Part</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
No.	No.			
1A.....	ZXOP-1A.....	3-Jaw Chuck (mounted on lathe).....	250, D1-8.....	1
1B.....	ZXOP-1B.....	Chuck Wrench .....		1
2A.....	ZXOP-2A.....	4-Jaw Chuck.....	300, D1-8.....	1
2B.....	ZXOP-2B.....	Chuck Wrench .....		1
3.....	ZXOP-03.....	300mm Face Plate (for 16" models) .....		1
	ZXOP-03N .....	400mm Face Plate (for 18" models) .....		1
4 .....	ZXOP-04 .....	Tool Tightening Wrench .....		1
5 .....	ZXOP-05 .....	Cam Tightening Wrench .....		1
6 .....	ZXOP-06 .....	Center .....		1
7 .....	ZXOP-07 .....	MT-4 Live Center (for 16" models) .....		1
	ZXOP-07N .....	MT-5 Live Center (for 18" models) .....		1
8 .....	ZXOP-08 .....	Morse Reduction Sleeve .....		1
9 .....	ZXOP-09 .....	Oil Gun.....		1
11 .....	ZXOP-11 .....	Gap Bridge Pin Driver.....		1
12 .....	ZXOP-12 .....	Hex Wrench .....	2, 2.5, 3, 4, 5, 6, 8, 10 . 8	
13 .....	ZXOP-13 .....	Double End .....		1
14 .....	ZX-10704G .....	Sliding Sleeve (for 14" models only).....		3
15 .....	ZXOP-14 .....	Flat Blade Screw Driver.....		1
	ZXOP-15 .....	Cross Point Screw Driver .....		1
16 .....	ZXOP-16 .....	Adjustable Wrench.....		1
17 .....	ZXOP-17 .....	Round Nut Wrench .....		1
18 .....	ZXOP-18 .....	Shear Pin .....		2
21 .....	ZXOP-21 .....	Indicate Bulb .....	110V or 24V.....	1
22 .....	ZXOP-22 .....	Taper Piece.....		1
23 .....	TNMP08501A .....	Gear (for 16" models) .....	3.5m35T .....	1
	TNMP08501B .....	Gear (for 18" models) .....	4m35T .....	1
24 .....	DTH-120 .....	Pads (serial #19011204 and higher) .....		6
24a .....	M16×115.....	Bolts (serial #19011204 and higher) .....		3
24b .....	M16×160 .....	Bolts (serial #19011204 and higher) .....		3
25 .....	GB5782-M12x40.....	Hex Head Cap Screw .....	M12x40.....	2
	GB97.2-12.....	Flat Washer.....	12 .....	2



**Electrical Components**






## Electric Cabinet

<b>Index</b>	<b>Part</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
No.	No.			
1	ZX-SB1E	Jog Button.....	XB7-EA1C .....	1
2	ZX-SA2E	Coolant Control Button .....	ZB2-BE101C .....	1
3	ZX-SB2ESB3E	Emergency Stop .....	ZB2-BE102C .....	2
4	ZX-HLE	Power Indicator Light.....	XB7-EVF3LC .....	1
5	SQ2SQ3E	Stroke Switch (not shown) .....	TM1306 .....	2
6	ZX-QF	Breaker (40A) (serial # 16051084 and lower) ...	DZ15-40 .....	1
	ZX-QF	Breaker (40A) (serial # 16081085 and higher) ...	NSC100B .....	1
7	ZX-FU1	Breaker (3A) (serial # 16051084 and lower) .....	.....	1
	ZX-QF1	Breaker (3A) (serial # 16081085 and higher) .....	DZ47-63 .....	1
8	ZX-FU2	Breaker (3A) (serial # 16051084 and lower) .....	.....	1
	ZX-QF2	Breaker (3A) (serial # 16081085 and higher) .....	DZ47-63 .....	1
9	ZX-FU3	Breaker (3A) (serial # 16051084 and lower) .....	.....	1
	ZX-QF3	Breaker (3A) (serial # 16081085 and higher) .....	DZ47-63 .....	1
10	ZX-FU5	Breaker (3A) (serial # 16051084 and lower) .....	.....	1
	ZX-QF4	Breaker (3A) (serial # 16081085 and higher) .....	DZ47-63 .....	1
11	ZX-QE	Temperature Relay (not shown) .....	JW6 .....	1
12	ZX-KM2E	A.C. Contactor .....	3TB40 .....	1
13	ZX-KAE	A.C. Contactor .....	3TH80 .....	1
14	ZX-KM3E	A.C. Contactor .....	3TB43 .....	1
15	ZX-KM4E	A.C. Contactor .....	3TB43 .....	1
16	ZX-XBE	Copper Plate (for grounding) .....	.....	1
17	ZX-XT1E	Wiring Board .....	JTL-25 .....	1
18	ZX-XT2E	Wiring Board .....	JF25 .....	1
19	ZX-TCE	Control Transformer .....	JBK5-160VATH .....	1
20	ZX-SQ1E	Stroke Switch (not shown) .....	JW2A-11H/W1 .....	1
21	SQ4E	Stroke Switch (not shown) .....	LXW5-11Q .....	1
22	SQ5E	Stroke Switch (not shown) .....	QKS8 .....	1
23	ZX-KM5E	A.C. Contactor (not shown) .....	3TB40 .....	1
24	ZX-KM6E	A.C. Contactor (not shown) .....	3TB40 .....	1
25	SQ6E	Stroke Switch (not shown) .....	LXW5-11Q .....	1
26	SQ7E	Stroke Switch (not shown) .....	LXW5-11Q .....	1
27	SA4	Button .....	ZB2-BE101C .....	1
28	ZX18301G	Operation Plate (serial # 16081101 and higher) .....	.....	1
28a	GB2672-M4x8	Screw (serial # 16081101 and higher) .....	M4x8 .....	7
29	C6140W18705	Small Shaft .....	.....	2
	C6140W18706	Pin Shaft .....	.....	2
	GB6170-M8	Hex Nut .....	M8 .....	2
30	ZX18703/9-G	Electric Box Door .....	.....	1
31	MS-705	Lock .....	.....	1
32	ZX18703-G	Electric Box .....	.....	1
33	GHB1340A18508-6	Warning Label .....	.....	1
34	AZ1-2004	Wiring Board .....	.....	1
	GB818-M4x6	Cross Recessed Pan Head Screw .....	M4x6 .....	2
	GB97.2-4	Flat Washer .....	4 .....	2
35	PG13.5-M20x1.5	Sheathed Wire Head .....	M20x1.5 .....	1

## **Wiring Diagram**



## **Flexible Stainless Wire Woven Tube**

1 .....	ZX-WLCP01 .....	Flexible Stainless Wire Woven Tube for Protecting Work Light Cable(for 1640/1840ZX) .....M20×1.5M20×1.5-1.7m .....	1
2 .....	ZX-WLCP02 .....	Flexible Stainless Wire Woven Tube for Protecting Work Button(for 1640/1840ZX)..... .....M16×1.5M16×1.5-1.6m .....	1
3 .....	ZX-WLCP03 .....	Flexible Stainless Wire Woven Tube for Protecting Work Light Cable(for 1860ZX) .....	
		.....M20×1.5M20×1.5-2.3m .....	1
4 .....	ZX-WLCP04 .....	Flexible Stainless Wire Woven Tube for Protecting Work Button(for 1860ZX)..... .....M16×1.5M16×1.5-2.3m .....	1
5 .....	ZX-WLCP05 .....	Flexible Stainless Wire Woven Tube for Protecting Work Light Cable(for 1880ZX) .....	
		.....M20×1.5M20×1.5-2.7m .....	1
6 .....	ZX-WLCP06 .....	Flexible Stainless Wire Woven Tube for Protecting Work Button(for 1880ZX)..... .....M16×1.5M16×1.5-2.7m .....	1
7 .....	ZX-DDCP01 .....	Flexible Stainless Wire Woven Tube for Protecting DRO Cable (for 1640/1840ZX with DRO).....M20×1.5-2.3m.....	1
8 .....	ZX-DDCP02 .....	Flexible Stainless Wire Woven Tube for Protecting DRO Cable (for 1860ZX with DRO) .....M20×1.5-2.7m.....	1
9 .....	ZX-DDCP03 .....	Flexible Stainless Wire Woven Tube for Protecting DRO Cable (for 1880ZX with DRO) .....M20×1.5-3.3m.....	1
10 .....	ZX-TPCG .....	Flexible Stainless Wire Woven Tube for Protecting Chuck Guard Cable .....	
		.....M16×1.5M16×1.5-0.8m.....	1
11 .....	ZX-TPRFS .....	Flexible Stainless Wire Woven Tube for Protecting Rapid Feed System Wires (for 1860/1880ZX) .....	2

